



Closed quick release



Open quick release

- 1 Turn the quick-release fastener with the sealing ring counterclockwise to disassemble it into two parts.
- 2 Insert the quick release with the winch from above into the opening of the melamine base and connect it to the counterpart again.
- 3 Press the lock inside the quick release to ensure smooth operation with the stainless steel rod.
- 4 Then insert the stainless steel rod from above into the opening of the quick release lock and fix the rod with the quick release.
- 5 Turn the second quick-release fastener with the sealing ring counterclockwise to disassemble it into two parts. Now guide the quick release with winch from below through the opening of the melamine bowl holder and connect it again to the counterpart.
- 6 Then put the melamine cup holder on the quick release so that the fixing piece is correctly seated in the intended fixing recess. The quick release can now be put down on the stainless steel rod. Select the desired height of the bowl holder and fix it with a quick release.
- 7 Finally place the bowls in the holders.

Contents

- Stainless steel rod
- Melamine bowl holder
- Melamine foot
- Two stainless steel feeding bowls with non-slip silicone rings
- Two quick release fasteners with sealing ring

PetTec® is a brand of
Ströer Products GmbH

Torstraße 49
10119 Berlin | Germany

www.PetTec.com | pettec.de/faq/doggybar